



Allgood lever furniture is unsprung and designed for use with heavily sprung mortice locks to achieve high endurance. Provided it has been installed correctly, your Allgood lever furniture should require only occasional checking and cleaning.

- Check the lever furniture for dirt and grease and wipe clean as directed in the 'Care of finishes' section (page 19-20).

monthly checks

- Check that all the fixings are tight and that the levers are properly aligned on each side of the door. Make sure the levers are firmly seated against the door and tighten the fixings under the roses (Fig.1). In persistent cases locktite should be applied to the fixings before re-tightening.
- Check the operation of the lever handles ensuring that they operate smoothly and return to the horizontal position at all times. If the handles are stiff to operate and do not return to the horizontal position, slightly loosen the grub screw (Fig.2) to rectify.

annual checks



Contego Satin Copper

Wipe clean with a solution of washing-up liquid using a soft cloth or sponge. Rinse and dry with a dry soft cloth. Do not use solvent based or abrasive cleaning materials.

Finish prefix: CS

Antimicrobial Copper **Cu⁺**



Contego Polished Copper

Wipe clean with a solution of washing-up liquid using a soft cloth or sponge. Rinse and dry with a dry soft cloth. Do not use solvent based or abrasive cleaning materials.

Finish prefix: CP

Antimicrobial Copper **Cu⁺**



Bronze

To protect the bronze items and to maintain a sheen, a regular application of an approved brass polish is required.

Finish prefix: BR



Brass

Polishing is the only way to prevent tarnishing. A weekly polish with a brass cleaner and a soft cloth will allow the brass products to maintain their original state.

Finish prefix: PB



Satin Stainless Steel

Wipe clean with a medium strength detergent or white spirit using a soft cloth or sponge. Rinse and dry with a dry soft cloth. In the event of dirt having accumulated through neglect, application of aerosol lubricant prior to standard cleaning is recommended. A harsh brush should never be used.

Finish prefixes: SS • ST



Polished Stainless Steel

Wipe clean with a medium strength detergent or white spirit using a soft cloth or sponge. Rinse and dry with a dry soft cloth. In the event of dirt having accumulated through neglect, application of aerosol lubricant prior to standard cleaning is recommended. A harsh brush should never be used.

Finish prefixes: PS • SP



Anodised Aluminium

Wipe clean with a solution of washing-up liquid using a soft cloth or sponge. Rinse and dry with a dry soft cloth. Do not use solvent based or abrasive cleaning materials.

Finish prefixes: MA • AS



Colour Coated / PVD

Wipe clean with a solution of washing-up liquid using a soft cloth or sponge. Rinse and dry with a dry soft cloth. Do not use solvent based or abrasive cleaning materials.

Finish prefixes: TA • BF • BS • BD • BL • BT • GT